



True Wireless Earphones & Charging Case

NE-985



Instruction Manual

Please read before operating product

Table of Contents

Introduction.....	3
Package Contents.....	3
Safety Instructions.....	4
Product Breakdown.....	6
How to Use.....	7
Bluetooth Operation.....	8
Power On/Off.....	9
Playback.....	10
Answering Calls.....	10
Charging Case.....	11
Specifications.....	12
Support.....	14

Introduction

Congratulations, and thank you for choosing Naxa's True Wireless Bluetooth® Earphones & Charging Case. This manual will help you operate your new device, but first you should familiarize yourself with the Bluetooth functionality of your mobile phone or other external devices before using the Naxa True Wireless Bluetooth® Earphones & Charging Case.

Package Contents

- NE-985
- USB Charging Cable
- Instruction Manual

Safety Instructions

Before using the device, read the operating instructions very carefully. Keep this operation manual for later reference.

1. Do not use an appliance for any purpose other than its intended use.
2. **WARNING:** Do not expose the appliance to extreme temperatures, to strong temperature fluctuations, direct sunlight or humidity.
3. To prevent any potential auditory damage, do not listen to music at high volumes for long periods.
4. No naked flame sources, such as lit candles, should be placed on the appliance.
5. This appliance should be used in temperate climate only.
6. Electric and electronic equipment should be disposed of separately. Do not discard used electric and electronic equipment with unsorted municipal waste but have them collected separately.
7. Attention should be drawn to the environmental aspects of battery disposal.

8. The appliance contains a battery or batteries that are non-replaceable.
9. Batteries (battery pack or batteries installed) shall not be exposed to excessive heat, such as sunshine, fire, or the like.
10. The battery must be removed from the appliance before being disposed of properly.
11. Only remove the rechargeable battery when you intend to dispose of the appliance. Have the rechargeable battery removed by trained professionals.
12. **CAUTION:** Risk of explosion if battery is replaced with the incorrect type of battery.
13. Dispose of used batteries according to the instructions.

Product Breakdown



1. MIC
2. Multi-Function Buttons
3. Earphone Dust Screen
4. Earphones Charging Port
5. Charging Port

How to Use

Unpack all parts and check for damage that may have occurred during transportation. If any parts are damaged or missing, contact our after-sales service team. Clean the appliance and its components.

- Fully charge the earphones and the case before first use.
- Charge the case first, or insert the earphones into the case to charge both at the same time, via the micro USB charging cable.
- Disconnect the USB cable after charging.

WARNING: Never use detergent, solvents/abrasive products, scouring pads, abrasive cleaners, sharp objects or wire brushes to clean the product.

Storage:

- Store the earphones in the charging case.
- Recharge the case regularly when not using it for extended periods of time (e.g. more than 6 months).

Bluetooth® Operation

1. Remove the earphones from the charging case.
2. Earphones are automatically on and attempting to pair.
3. Turn on Bluetooth on your connecting (mobile) device. Search for the earphones on your device and choose the name "Naxa E-985" to connect.
4. After pairing is successful, the blue LEDs on both earphones will blink slowly, letting you know a successful connection has been established.

NOTE: If you have paired the earphones successfully, the earphones will automatically reconnect to the paired device the next time you turn them on within range of each other and when Bluetooth is enabled on your mobile device.

Wireless earphones can be connected separately to other Bluetooth devices.

Power On/Off

1. Remove the earphones from the case. The earphones will automatically turn on, or press and hold the earphones buttons for 3 seconds to turn on.
2. Place the earphones into the case, or press and hold the earphones buttons for 3 seconds to turn off.
3. The earphones will automatically power off if not connected with any external devices within 5 minutes of being turned on.

Playback

1. To play a song from your mobile phone through your Bluetooth earphones, press the multi-function button once.
2. To pause a song, press the multi-function button once again.
3. To return to the previous song, press the right earphone button 3 times. To go to the next song, press the left earphone button 3 times.
4. To turn the volume down, press the right earphone button 2 times. To turn to volume up, press the left earphone button 2 times.

Answering Calls

1. To answer incoming calls, press the multi-function button once.
2. To end a call, press the multi-function button again.
3. To reject an incoming call, press and hold the multi-function button.

Charging Case

When fully charged, the case provides 2.5 full charges to the earphones.

1. Insert the micro-USB connector into the micro-USB charging port (5) the back of the case.
2. Connect the USB-A plug on the cable into your computer or a USB power adapter plugged into a wall socket.
3. Disconnect the USB cable when charging is complete.

Specifications

Bluetooth® Version: 5.0

Earphones battery: 40MAh per single

Charging Case Battery: 300MAh

Transmission Distance: 10m

Frequency: 2.4GHZ

Charging time: 1.5-2 hours

Play time: 3-5 hours

Standby time: About 100 hours

FCC NOTICE

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) this device may not cause harmful interference.

(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits

are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference, will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION ON MODIFICATIONS

Any changes or the modifications not expressly approved by the grantee of this device may void the authority granted by the FCC to operate the equipment.

Support

If you have problems with your device, please consult the instructions in this manual. Please also visit us on the web at www.naxa.com to get up to the minute news, alerts, and documentation for your device. For additional assistance, please contact Naxa Technical Support.

NAXA Technical Support

2320 East 49th St.
Vernon, CA 90058

http://www.naxa.com/naxa_support/
MADE IN CHINA