

## Portable 12" Bluetooth Party Speaker with Disco Light Model: NDS-1234









Connect Two of the Same Speaker wirelessly with One Bluetooth® Source TRUE WIRELESS STEREO FUNCTION

## **FEATURES:**

- Wirelessly stream all of your favorite media content via Bluetooth®
- Connect to other Sound Pro NDS-1234 TWS speakers allowing you to sync speakers up to 33 feet from each other without any wires
- LED (Red) Display make for an easy-to-use user experience
- Release your inner Rock star with friends and family thanks to the included wired microphone
- Start the party off right with the Disco Light
- Full-frequency speaker pumps out room-filling, high-quality audio with ease
- Enjoy media from removable storage devices, such as USB flash drives and Media cards via the USB input and TF card slot
- Manually connect external media devices via the included auxiliary input jack
- ${\boldsymbol{\cdot}}$  Tune in on all your favorite local radio stations thanks to the FM tuner
- Fully control your entertainment experience with the 5 control knobs
- Built-in trolley and wheels allow you to move the speaker anywhere easily
- Accessories included: Wired microphone, Remote control, Power adapter, User manual
- Product Dimensions: 14.2" x 12.5" x 21.3"
- UPC: 840005015674
- \* For more detailed information about this product including set up information, please download the Setup sheet for this item from the Naxa site.
- \* Features, specifications, measurements and weights may be subject to change without prior notice.



















CONTROL

## NDS-1234 WITH DISCO LIGHT 380x346x578MM **12" WIRELESS SPEAKER** 12" WIRELESS SPEAKER 12" WIRELESS SPEAKER WITH DISCO LIGHT WITH DISCO LIGHT 🕏 Bli BOLINE . 1 The part of the pa 80