



Wi-Fi Smart Camera NSH-3000




User Manual


Thank you for using the Wi-Fi Smart Camera

1. Product Introduction


Packing list: Smart Camera x 1, Manual x 1, USB Power Cord x 1, Power Adapter x 1, Screw Accessories Package x 1



Smart Camera




Screw Accessories Package



USB Power Cord



Manual



Power Adapter

01

Specifications

Product Name: Smart Camera
Lens: 110° wide angle
Pixel: 1.0Mp/2.0MP
Video Compression: H.264 High Profile
Image Enhancement: Digital Wide Dynamic 3D Noise Reduction
Local Storage: MicroSD card
Wireless Encryption: WEP/WPA/WPA2 Encryption
Power Input: 5V 1.6A
Total Power Consumption: 3.5W (Max)
Wireless Standard: 2.4G 802.11 b/g/n
Support Platform: Android/iOS

Getting Started

Reset Button: Press a small object into the "Reset" hole on the back of the device and hold for 5 seconds. A voice prompt will state "Reset camera successfully" when properly completed.
It is recommended that you insert an 8-64GB high-speed Micro SD card. Otherwise, the camera will not be able to store, view old video, or support important functions, such as firmware upgrading.

02

2. Install the Smart Life App

Download the Smart Life App: Access the Smart Life app from your Google Play / Apple App Store or scan the QR code below to download and install.
Register and Login: Open the Smart Life App and follow the prompts to register and log in.




03

3. Add The Device


Please make sure that there is an available Wi-Fi network and that you are connected to the internet.
Find the USB port on the bottom of the smart camera and insert the power cord to turn on the device.

Then go to the Smart Life app home page and click "ADD DEVICES" on the main screen. Choose "Security camera".
Select the "QR Code" in the upper right corner of the screen. Click confirm and proceed according to the prompts on your mobile phone.



04

4. Video Browsing in the Smart Life App



- ① Preview mode
- ② Monitor Switch
- ③ More device
- ④ SQ

05

- ⑤ Full screen
- ⑥ Play / Pause
- ⑦ History file (Make sure insert Micro SD card)

06

5. App Interface

1. Click the to enable the microphone function. By holding the speaker button down, you can communicate with the people/pets that you see on screen with the camera. Click when the listening functionality is on and you can hear audio from the camera end.
2. Click to adjust the camera.
3. Click or to start recording or take a screenshot (files recorded in mobile phone).
4. Click to view the motion sensor and alerts settings. (Three sensitivity options: Low, Medium, High.)
5. Click to view in full-screen mode.
6. Image-quality adjustment: Two modes, SD and HD).
7. Recording and playback: You can watch the recorded videos on the local disc and SD card.
8. Alarm notification and triggered screenshot can be viewed in the message center.

6. More Settings

1. Click to view more settings.
2. Device Sharing: Share the device to multiple users with the Smart Life app (only the admin account is allowed to change the settings).
3. Device info: IP address, device ID, timezone, and Wi-Fi signal (6.2).
4. Basic features settings: Set flip and time stamp.
5. SD card settings: Check the status of the SD card and set recording and alarm mode.

7. Important Reminders

- Avoid contact with sharp objects,
- Avoid placing on furniture or places where it might fall.
- Avoid tangling the wires, and keep them tucked away from the camera to avoid tripping hazards and pinching.
- Ensure that the camera is within coverage range of the wireless Wi-Fi signals.
- When switching to a new network environment: Reset the camera via the reset hole on the back, by inserting a small object and holding the reset button for about 5 seconds. A voice prompt will state "Reset camera successfully". Then you may connect to the new network.

07

8. FCC Notice

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

08

9. Trademark & Regulatory Statements

The Smart Life App and all Smart Life Features are a trademark of Tuya, LLC.

Google Play™ store and all Google Brand Features are trademarks of Google Inc., LLC.

Apple App Store™ and all Apple Brand Features are registered trademarks or trademarks of Apple Inc.

8. Support

If you have problems with your device, please consult the instructions in this manual. Please also visit us on the web at www.naxa.com to get daily news, alerts, and documentation for your device. For additional assistance, please contact Naxa Technical Support.

NAXA Technical Support

2320 East 49th St.
Vernon, CA 90058
<http://www.naxa.com/supportcenter/>

09