

naxa
THE NEW GENERATION IN TECHNOLOGY

NE-946

Three-in-One Bluetooth® Fitness Combo
Bluetooth® Sport Earphones
Sports Armband
Bluetooth® Fitness Tracker

Instruction Manual
Please read carefully before use and keep for future reference.

Booklet

100x 70mm

naxa
THE NEW GENERATION IN TECHNOLOGY

Thank you for purchasing the NAXA Three-in-One Bluetooth® Fitness Combo. This booklet provides more information about the NE-946, please read the instructions before using them.

CONTENTS

Page 1 - 2 ----- **Bluetooth® Sport Earphone** instructions
 Page 2 - 3 ----- **Sports Armband** instructions
 Page 4 - 18 ----- **Bluetooth® Fitness Tracker** instructions
 Page 19 ----- Specifications
 Page 20-22 ----- Warnings and Precautions
 Page 23 ----- Support

Page 2 Naxa Electronics

Bluetooth® Sport Earphones
Earphones Overview

Page 3 Naxa Electronics

Power On/Off

Power on
Press and hold down the Multi-Function Button(MFB) for 3 seconds and the blue LED will light.

Power off
Press and hold down the Multi-Function Button(MFB) for 4 seconds and the blue LED will turn off.

Pair NE-946 with your mobile phone

1. Keep the distance between your wireless sports earphones and mobile phone (or other devices) within 1 meter.
2. Press the Multi-Function Button for 5 seconds until the red and blue light flash alternatively which indicates that your earphone is in pairing mode.

Activate the Bluetooth devices on your phone within range and select "NAXA NE-946" from the list of devices shown. The LED blinks in blue when paired successfully.

Attention: If the pairing is not successful within 2 minutes, the earphones will power off, please repeat the pairing procedure to try again.

Page 4 Naxa Electronics

Reconnect NE-946 to your mobile phone

When powered on, the earphones will automatically connect with the last successfully paired devices.

Disconnect the earphones from your mobile phone

Power off the earphones; or Switch off the Bluetooth® on your mobile phone; or Leave the earphones 60ft away from your mobile phone or further.

Answer a call

When you receive a call, press the Multi-Function Button once to accept the call, or answer the call normally via your mobile phone.

End a call

Press the Multi-Function Button once to end the call or hang up your mobile phone.

Page 5 Naxa Electronics

Sports Armband
Armband Overview

Page 5 Naxa Electronics

Armband instruction

1. Soft transparent window protect your phone from scratch and rub, and you can handle your cell phone function no obstacles.
2. Adjustable lanyard, you can adjust the size as your actual need
3. Hang Bag Design, Using for storing your keys or small spare funds at any time

Page 6 Naxa Electronics

Bluetooth® Sport Earphones
Tracker Overview

1 Mode	Mode button. Press to change the display mode (time, steps, calories, distance, stop watch). While the time is displayed, press and hold to switch between active and sleep modes.
2 Display	OLED display shows the time, mode, and power status. The time will automatically be set when you sync data with the smartphone app.
3 Reset	Press to reset the band if it behaves abnormally.
4 Micro USB charge port	Connection for power. Use the included USB cable to connect to a USB power source.

Page 7 Naxa Electronics

Getting Started

What You'll Need

- An internet connection
- A fully charged NSW-11
- A supported smartphone or tablet that has the following:
 - Bluetooth 4.0
 - Android OS or iOS

Charging the Module

The module contains all of the sensors and processors, as well as a built-in rechargeable battery that will need to be charged from time to time.

Use the included USB cable to charge the module.

1. Remove the main module from the fitness band.
2. Connect the small end of the cable to the USB port

Page 8 Naxa Electronics

Use with an Android Device

This fitness band will work with the following Android devices:

- SAMSUNG GALAXY S5, Android 4.3
- SAMSUNG GALAXY S4, Android 4.3
- SAMSUNG GALAXY S3, Android 4.3
- SAMSUNG GALAXY NOTE 2, Android 4.3
- SAMSUNG GALAXY NOTE 10.1, Android 4.3

The fitness band may work with other devices that support Bluetooth 4.0 and Android 4.3, but compatibility cannot be guaranteed with all devices.

Getting the Bluetooth Health Watch App

1. Find and tap the Google Play store app on your device to launch it.

Page 9 Naxa Electronics

2. Tap the magnifying glass at the top right corner.

3. Type Bluetooth Health Watch into the search box. In the list of search results below, tap "Bluetooth Health Watch".

4. Tap the green Install button. Follow the on-screen instructions to finish downloading and installing the app.

Page 10 Naxa Electronics

Bluetooth Health Watch App

1. Find and tap the BlueHealth icon to launch the app.

Page 11 Naxa Electronics

2. The app will present a personal setup screen. Tap in each field to set your starting information. The fitness band requires this info to accurately track your activity. Tap "Continue" when you're finished entering your info.

3. The Home screen gives you access to all of the app's functions. You will first need to sync the data from the fitness band to the app. Tap "sync" to begin.

Page 12 Naxa Electronics

4. The app will automatically scan for the NSW-11 fitness watch.

5. Once it finds the watch, it will appear in the results list. Tap "BlueHealth" to finish the pairing/binding process.

Page 13 Naxa Electronics

6. After a successful pairing/binding, you will see the following screen. Tap OK to continue on.

Tap the sync button every time you launch the app to make sure you have access to the latest data.

Page 14 Naxa Electronics

Use with an iOS Device

This fitness band will work with the following Apple iOS devices:

- iPhone 4S
- iPhone 5
- iPhone 5s
- iPhone 5c
- iPhone 6
- iPhone 6 plus
- iPod touch (5th gen)
- iPad 3
- iPad Air
- iPad mini
- (and newer iPads)

Getting the Bluetooth Health Watch App

1. Find and tap the App Store icon on your device to launch it.
2. Tap the magnifying glass at the top right corner.

Page 15 Naxa Electronics

3. Type Bluetooth Health Watch into the search box. Tap "Bluetooth Health Watch" in the results panel. (Make sure you are searching for "iPhone only" apps.)

4. Tap the "Get" button and then the "Install" button. Follow the on-screen instructions to finish downloading and installing the app.

Bluetooth Health Watch App

1. Find and tap the BlueHealth icon to launch the app.

Page 16 Naxa Electronics

2. The app will present a personal setup screen. Tap in each field to set your starting information. The fitness band requires this info to accurately track your activity. Tap "Continue" when you're finished entering your info.

3. The Home screen gives you access to all of the app's functions. You will first need to sync the data from the fitness band to the app. Tap "sync" to begin.

Page 17 Naxa Electronics

2. Tap the magnifying glass at the top right corner.

3. Type Bluetooth Health Watch into the search box. In the list of search results below, tap "Bluetooth Health Watch".

4. Tap the green Install button. Follow the on-screen instructions to finish downloading and installing the app.

Page 10 Naxa Electronics

Bluetooth Health Watch App

1. Find and tap the BlueHealth icon to launch the app.

Page 11 Naxa Electronics

4. The app will automatically scan for the NSW-11 fitness watch.

5. Once it finds the watch, it will appear in the results list. Tap "BlueHealth" to finish the pairing/binding process.

Tap the sync button every time you launch the app to make sure you have access to the latest data.

Page 18 Naxa Electronics

Specifications

Bluetooth® Sport Earphones

Bluetooth® version: V2.1+EDR
 Supported profiles: A2DP, AVRCP, HSP, HFP
 Transmission frequency range: 2.4GHz-2.48GHz
 Bluetooth® operating range: up to 32ft (free space)
 Frequency response: 20Hz-20KHz
 Bluetooth® music / talk time: 6-8hrs
 Standby time: 200hrs
 Fully charged time: 1.5hrs
 Operating environment: -10 to 50 °C

Bluetooth® Fitness Tracker

Pedometer function
 Calories burned
 Sleep monitoring
 30 day memory function
 Bluetooth® version: V4.0+EDR
 Frequency range: 2.402-2.480 GHz
 Operating range: 10 meters
 Battery capacity: 3.7V / 100mAh
 Input: DC 5V

Page 19 Naxa Electronics

Warnings and Precautions

CAUTION

WARNING: SHOCK HAZARD. DO NOT OPEN. RISQUE DE CHOC ELECTRIQUE. NE PAS OUVRIRE.

CAUTION: TO REDUCE THE RISK OF FIRE AND ELECTRIC SHOCK, DO NOT REMOVE THE COVER (OR BACK) OF THE UNIT. REFER SERVICING ONLY TO QUALIFIED SERVICE PERSONNEL.

Important Safety Information

1. Read Instructions: All the safety and operating instructions should be read before the product is operated.
2. Retain Instructions: The safety and operating instruction should be retained for future reference.
3. Heed Warnings: All warnings on the product and in the operating instructions should be adhered to.
4. Follow Instructions: All operating and usage instructions should be followed.
5. Cleaning: Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
6. Attachments: Use only attachments recommended by the manufacturer. Use of other attachments may be hazardous.
7. Water and Moisture: Do not use this product near water (e.g., near a bathtub, washbowl, kitchen sink, laundry tub, in wet basements, or near a swimming pool and the like).
8. Power Source: This product should be operated only from the type of power source indicated on the rating label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power or other sources, refer to the operating instructions.
9. Grounding or Polarization: This product may be equipped with a polarized alternating current line plug that has one blade wider than the other. This plug will only fit into the power outlet in one direction. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the direction of the plug. If the plug should not fall in, contact and electrician to replace the obsolete outlet. Do not defeat the safety purpose of the polarized plug.
10. Power Cord Protection: Power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them. Paying particular attention to cords at plugs, convenience receptacles, and at the point which they exit from the product.
11. Protective Attachment Plug: The product may be equipped with an attachment plug with overload protection. This is a safety feature. See the operating instructions for replacement or directions to reset the service technician has used a replacement plug that has the same overload protection as the original plug as specified by the manufacturer.
12. Overloading: Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
13. Object and Liquid Entry: Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.
14. Servicing: Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
15. Damage Requiring Service: Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions: a) when the power supply or plug is damaged; b) if liquid has been spilled or if objects have fallen into the product; c) if the product has been exposed to rain or water; d) if the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation. e) if the product has been dropped or damaged in any way; f) when the product exhibits a distinct change in performance—this indicates a need for service.
16. Replacement Parts: When replacement parts are required, be sure that your service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.
17. Safety Check: Upon completion of any service or repairs to this product, the service technician to perform safety checks to ensure that the product is in proper operating condition.
18. Heat: The product should be situated away from heat sources such as radiator, heat registers, stoves, or other products (including amplifiers) that produce heat.

WARNING:
 This product contains lead, a chemical known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

FCC NOTICE
 This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION ON MODIFICATIONS
 Any changes or modifications not expressly approved by the grantee of this device may void the authority granted by the FCC to operate the equipment.

Trademark & Regulatory Statements
 Bluetooth® is a registered trademark of Bluetooth SIG, Inc. Other trade marks and names are those of their respective owners.

Page 20 Naxa Electronics

will fail to fit, contact and electrician to replace the obsolete outlet. Do not defeat the safety purpose of the polarized plug.

10. Power Cord Protection: Power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them. Paying particular attention to cords at plugs, convenience receptacles, and at the point which they exit from the product.

11. Protective Attachment Plug: The product may be equipped with an attachment plug with overload protection. This is a safety feature. See the operating instructions for replacement or directions to reset the service technician has used a replacement plug that has the same overload protection as the original plug as specified by the manufacturer.

12. Overloading: Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.

13. Object and Liquid Entry: Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.

14. Servicing: Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

15. Damage Requiring Service: Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions: a) when the power supply or plug is damaged; b) if liquid has been spilled or if objects have fallen into the product; c) if the product has been exposed to rain or water; d) if the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation. e) if the product has been dropped or damaged in any way; f) when the product exhibits a distinct change in performance—this indicates a need for service.

16. Replacement Parts: When replacement parts are required, be sure that your service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.

17. Safety Check: Upon completion of any service or repairs to this product, the service technician to perform safety checks to ensure that the product is in proper operating condition.

18. Heat: The product should be situated away from heat sources such as radiator, heat registers, stoves, or other products (including amplifiers) that produce heat.

WARNING:
 This product contains lead, a chemical known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

FCC NOTICE
 This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION ON MODIFICATIONS
 Any changes or modifications not expressly approved by the grantee of this device may void the authority granted by the FCC to operate the equipment.

Trademark & Regulatory Statements
 Bluetooth® is a registered trademark of Bluetooth SIG, Inc. Other trade marks and names are those of their respective owners.

Page 21 Naxa Electronics

2. Tap the magnifying glass at the top right corner.

3. Type Bluetooth Health Watch into the search box. In the list of search results below, tap "Bluetooth Health Watch".

4. Tap the green Install button. Follow the on-screen instructions to finish downloading and installing the app.

Page 10 Naxa Electronics

Support

If you have problems with your device, please consult the instructions in this manual. Please also visit us on the web at www.naxa.com to get up the minute news, alerts, and documentation for your device. For additional assistance, please contact Naxa Technical Support.

NAXA Technical Support
 2320 East 49th St.
 Vernon, CA 90058
http://www.naxa.com/naxa_support/

Page 23 Naxa Electronics