



**NE-945**

**Three-in-One Bluetooth® Power Combo**  
 Bluetooth® Sport Earphones  
 Bluetooth® Headphones  
 Portable Battery Pack



**Instruction Manual**  
 Please read carefully before use and keep for future reference.




Thank you for purchasing the NAXA Three-in-One Bluetooth® Power Combo. This booklet provides more information about the NE-945, please read the instructions before using them.

**CONTENTS**

Page 3 - 4	-----	<b>Bluetooth® Sport Earphone</b> instructions
Page 5 - 7	-----	<b>Bluetooth® Headphones</b> instructions
Page 8 - 10	-----	<b>Portable Battery Pack</b> instructions
Page 11	-----	Specifications
Page 12	-----	Support

**Bluetooth® Sport Earphones**

**Earphones Overview**



**Power On/Off**

**Power on**  
 Press and hold down the Multi-Function Button(MFB) for 3 seconds and the blue LED will light.

**Power off**  
 Press and hold down the Multi-Function Button(MFB) for 4 seconds and the blue LED will turn off.

**Pair NE-945 with your mobile phone**

- Keep the distance between your wireless sports earphones and mobile phone (or other devices) within 1 meter.
- Press the 'Multi-Function Button' for 5 seconds until the red and blue light flash alternately which indicates that your earphone is in pairing mode.

Activate the Bluetooth devices on your phone within range and select "NE-945" from the list of devices shown. The LED blinks in blue when paired successfully.

Attention: If the pairing is not successful within 2 minutes, the earphones will power off, please repeat the pairing procedure to try again.

**Reconnect NE-945 to your mobile phone**  
 When powered on, the earphones will automatically connect with the last successfully paired devices.


**Disconnect the earphones from your mobile phone**  
 Power off the earphones; or Switch off the Bluetooth® on your mobile phone; or Leave the earphones 60ft away from your mobile phone or further.


**Answer a call**  
 When you receive a call, press the Multi-Function Button once to accept the call, or answer the call normally via your mobile phone.

**End a call**  
 Press the Multi-Function Button once to end the call or hang up your mobile phone.

**Bluetooth® Headphones**

**Headphones Overview**



Desired Result	Required Action
Turn on & Enter the pairing mode	Press and hold the On / Off Button for 3 seconds until the LED indicator light turns on.
Pairing	Use a Bluetooth® enabled mobile phone or other Bluetooth enabled device to perform necessary pairing actions.
Turn off	Press and hold the On / Off Button for 3 seconds until the LED indicator turns off.
Charging	Plug the Micro USB into the  port.
Answering a Call	Press the On / Off button to answer phone calls, press the On / Off button again to end calls.
Play / Pause Music	Press the On / Off button to play music and press it again to pause music.

**Pairing to a mobile phone or other device**  
 To use your Bluetooth® headphones, you must first pair your headphones with a phone or a computer. Once your Bluetooth® headphones are paired to a specific mobile device, they will remain paired and automatically recognize each other whenever they are within range.


**Pairing to a Bluetooth® Enabled Mobile Phone**

- Turn on your phone and ensure the Bluetooth® function is activated.
- Turn on the headphones, enter the pairing mode.
- Search the Bluetooth® devices on your phone by following the phone's instructions. Refer to your phone's user manual for more information.
- After a few seconds the phone will list the "NE-945" as a discover device. Select it and follow your phone's instructions to select this pairing.
- You can play music, watch TV shows/movies, and play games with your device, with all of the sound coming from the headphones.

**Charging your headphones**

Use the Micro USB cable provided with these headphones. Connect the Micro USB plug to the Micro USB charging port on the headphones. Connect the USB plug to a USB port on a computer or wall adapter to activate charging.

**\*\*Make sure to keep the headphones charging for a minimum of 6 hours before initial use.**




**Warning:**

- You must select a qualified charger from a regular manufacturer.
- You must charge the Bluetooth headphones if it has been not used for more than 12 months.

**Portable Battery Pack**

**Power bank Overview**



<table border="1"> <tr> <td>1</td> <td>Micro USB port</td> <td>Power input. Use this port to charge the battery pack with the included USB charge cable.</td> </tr> <tr> <td>2</td> <td>USB port</td> <td>Power output. Use this port to charge other devices with the USB cable provided by the device's manufacturer.</td> </tr> <tr> <td>3</td> <td>Status LED</td> <td>Lights up to show the current status of the battery pack.</td> </tr> <tr> <td>4</td> <td>USB charge cable</td> <td>Use the USB charge cable to connect the battery pack to a USB power source.</td> </tr> </table>	1	Micro USB port	Power input. Use this port to charge the battery pack with the included USB charge cable.	2	USB port	Power output. Use this port to charge other devices with the USB cable provided by the device's manufacturer.	3	Status LED	Lights up to show the current status of the battery pack.	4	USB charge cable	Use the USB charge cable to connect the battery pack to a USB power source.	<p>When charging, the RED light will start blinking and once fully charged, the RED light will stop blinking, it will remain stable.</p> <p><b>i</b> Fully charge the battery pack for at least 5 hours when using the battery pack for the first time.</p> <p><b>⚠</b> The battery used in this device may present a fire or chemical burn if mistreated. Do not disassemble, incinerate, or heat the battery. Do not leave the battery in a place subject to direct sunlight, or in a car with its windows closed.</p> <p>Do not connect the unit to a power source other than that which is indicated here or on the label as this may result in the risk of fire or electric shock.</p>
1	Micro USB port	Power input. Use this port to charge the battery pack with the included USB charge cable.											
2	USB port	Power output. Use this port to charge other devices with the USB cable provided by the device's manufacturer.											
3	Status LED	Lights up to show the current status of the battery pack.											
4	USB charge cable	Use the USB charge cable to connect the battery pack to a USB power source.											

**Charging the Battery Pack**  
 Use the included USB Cable to connect the speaker to a USB power source to charge the battery.

- Connect the small end of the cable to the micro USB Charge port of the unit.
- Connect the large end of the cable to a high-power USB port of a computer or other USB power source.

**Using the Battery Pack to Charge Your Devices**

Use the cable included with your device to charge it.

- Connect the end that goes into your device as usual.
- Connect the large end of the cable to the large USB port of the battery pack.

**i** For optimal performance, fully charge the battery pack before using it to charge another device.

**Care and Maintenance**

Please read and follow the recommendation below when using the Portable Battery Pack.

- Do not expose the device to liquid, moisture, or humidity. This may adversely affect the device's internal circuit.
- Do not use abrasives or solvents to clean the device.
- Do not expose the device to extremely high or low temperatures as it may damage the device or deform the plastic parts of the device.
- Do not incinerate the device to dispose of it as it may cause an explosion.
- Do not allow the device to come into contact with sharp objects to prevent scratches or other damage.
- Do not drop the device or subject it to any strong shocks or other impact. This may damage the internal circuit of the device.
- Do not attempt to disassemble the device. There are no user-serviceable parts inside.

**Specifications**

<p><b>Bluetooth® Sport Earphones</b></p> <p>Bluetooth® version: V2.1+EDR              Supported profiles: A2DP, AVRCP, HSP, HFP              Transmission frequency range: 2.4GHz-2.48GHz              Bluetooth® operating range: up to 32ft (free space)              Frequency response: 20Hz-20KHz              Bluetooth® music / talk time: 6-8hrs              Standby time: 200hrs              Fully charged time: 1.5hrs              Operating environment: -10 to 50 C</p>	<p><b>Bluetooth® Sport Earphones</b></p> <p>Driver Diameter: 40mm              Frequency Range: 20Hz-20KHz              Sensitivity: 110db              Impedance: 32ohm±10%              Bluetooth® version: V2.1              Power Supply: Lithium-ion Battery              Voltage: 3.7V              Receiver Distance: ≤ 32.8 Feet              Charging Time: 3 Hours              Standby Time: 50 Hours</p>
--	--

**Portable Battery Pack**

Capacity: 2,200 mAh  
 Charge connector: USB  
 Power Output: DC 5V, 1A  
 Power Input: DC 5V, 1A

**Support**

If you have problems with your device, please consult the instructions in this manual. Please also visit us on the web at [www.naxa.com](http://www.naxa.com) to get up the minute news, alerts, and documentation for your device. For additional assistance, please contact Naxa Technical Support.

**NAXA Technical Support**  
 2320 East 49th St.  
 Vernon, CA 90058  
[http://www.naxa.com/naxa\\_support/](http://www.naxa.com/naxa_support/)