


#### Wireless Power Bank with Suction Cups & USB

NAP-56



#### Instruction Manual

Please read carefully before use and keep for future reference.

#### Thank You

We know you have many choices when it comes to technology; thank you for choosing us here at Naxa Electronics. Established in 2001 in Los Angeles, California, we are dedicated to delivering products that entertain and delight.

We trust that you will be happy with your purchase. Please read this manual carefully and save it for reference. You may also find the latest FAQ, documentation, and other product material at our website. Come visit us on the web at www.naxa.com and see all that we have to offer!

#### In the Box

Please take a moment to make sure that you have everything in the list below. Although we make every effort to ensure that each Naxa device is securely packed and sealed, we know a lot can happen in between us and you. If anything is missing, check back with your local retailer to get immediate assistance.

If they cannot help you, please contact our Naxa Support team at www. naxa.com/naxa\_support.

- NAP-56
- micro-USB charging cable
- · Instruction manual
- · Warranty card

## **Key Features**

- Wireless charging pad allows you to charge your devices wirelessly
- Portable battery pack provides 10000 mAh of power when you need it most
- Suction grips hold your devices firmly in place during use
- Two USB ports allow you to manually connect multiple ways and charge while on the move
- Ultra-compact design makes it easy to keep power with you always
- Four-stage battery status indicator
- Recharge the battery pack with the included micro USB cable or via type-c USB port.

# Warning 🗥


- 1. Keep the unit from heat sources, direct sunlight, humidity, water or any other form of liquid.
- Do not operate the unit if it has been wet or exposed to moisture to prevent electric shock, explosion, and/or injury to yourself or damage to the unit.
- 3. Do not use the unit with wet hands.
- 4. Keep the unit free from dust, lint and other small particles.
- 5. Do not use the unit for anything other than its intended use.
- 6. Keep the unit out of reach of children. This unit is not a toy
- 7. Do not expose the battery to liquid, moisture or humidity. This may adversely affect the internal circuit of the device.
- 8. Do not use abrasive cleaning solvents to clean the device.
- 9. Do not expose the device to extremely high or low temperatures. Extreme temperatures may destroy the battery or distort some of the plastic parts.
- 10. Do not incinerate or otherwise dispose of the device in fire as it may result in an explosion.
- 11. Do not expose the device to contact with sharp to prevent scratches and other damage.
- 12. Do not drop the device. Drops and other hard shocks may damage the internal circuit.
- 13. Do not attempt to disassemble the device. There are no user-serviceable parts inside.









#### At A Glance



## Wireless Charging




To charge your mobile device wirelessly, be sure to lay the power bank so the suction grips are facing up and place your mobile device onto the power bank with the screen facing down, as shown below.



For optimal efficiency during wireless charging, align the wireless charging area of the device with the wireless charging receiving area of your mobile device. For most models, this device ensure the camera is not blocked during use.

## **Suction Grips**



The suction grips on the face of the device help to secure your mobile device in place during use. Ensure the suction grips are working properly by helping to maintain their condition. To do so, clean the grips when dirty using a damp cloth to lightly clean the device, as shown below.




#### **USB Ports**

When the device is out of power, or low on battery, then you need to charge the device. You can use the standard USB charging cable with micro-USB connector to connect the device and plug the USB-A into a 5V2A external power source, such as a car charger, household appliance, etc.

To charge external devices with the power bank via USB:

- 1. Insert the USB-A end of the power cable into the Output port.
- 2. Plug the other end of the cable into the input port of the external device you wish you charge.
- 3. Press the power button to power on the power bank and begin charging your external device.



#### How to Use

To operate the device, press the power button once to turn the device on. It is now in standby mode and other devices can be charged.

When powered on, press the power button twice quickly, or press and hold the button for 15 seconds to turn the device off.

NOTE: In standby mode, if you do not perform any operations, it will automatically shut down after about 20 seconds. If you need to use it again, please repeat to powering on process.




## **Indicator Lights**

This device comes with a four-stage battery indicator, allowing you to efficiently track the power level of the device at all times. This light is a steady blue.

It also comes with a charging indicator light that keeps you aware of its status in charging external devices.

- If the charging light is steady green, it is currently wireless charging.
- · If the light is red, it is in standby mode.
- If the light flashes red and green alternatively, there is an issue with the charging connection.



## **Specifications**

Capacity: 10000mAh Micro B Input: 5V/2A Type-C Input: 5V/2A

Transmission Distance: <6mm

USB Output: 5V/2A Wireless Output: 5V/1A Charging Efficiency: ≥75% Product size: 101 x 67.5 x 22 mm

## Support

If you have problems with your device, please consult the instructions in this manual. Please also visit us on the web at www.naxa.com to get up to the minute news, alerts, and documentation for your device. For additional assistance, please contact Naxa Technical Support.

NAXA Technical Support 2320 East 49th St. Vernon, CA 90058

http://www.naxa.com/naxa\_support/ MADE IN CHINA

品名:	NAXA-Box-10000W-NAP-56-EN说明书	规格:	128g 双铜 黑白 双面印刷 5折页 尺寸:90x140 mm
版本:	20191219		
制作:	杨忠飞		,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
料号:			

10.0105.0397 Box 10000W说明书 NAXA(NAP-56-EN 英文)

128g铜板纸/单色双面印刷/90\*140mm/五折